BJC-2000

SERVICE MANUAL

REVISION 0

Canon

OCT. 1998 **QY8-1362-000**

COPYRIGHT © 1998 CANON INC. CANON BJC-2000 1098 SC 0.40-0 PRINTED IN JAPAN (IMPRIME AU JAPON)

1098 SC 0.40-0

BJC-2000

SERVICE MANUAL

Canon

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual could include technical inaccuracies or typographical errors due to improvements or changes in the products. When changes occur in applicable products or in the content of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new editions of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names described in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc., except in the case of internal business use.

Copyright © 1998 by Canon Inc.

CANON INC.
BJ Products Technical Support Dept
16-1, Shimonoge 3-chome, Takatsu-ku, Kawasaki-shi, Kanagawa 213, Japan

This manual was produced on an Apple Macintosh™ Power Mac 8500/180 personal computer and Apple LaserWriter™ 16/600PS-J laser beam printer; final pages were printed on Varityper™ 5300 with 4000-J RIP. All graphics were produced with MACROMEDIA® FREEHAND® 7.0J.
All documents and all page layouts were created with QuarkXPress™ 3.3J.

I. ABOUT THIS MANUAL

This manual is divided into four sections, and contains information required for servicing the unit.

Part 1: Safety and Precautions

This section tells you how to service the unit safely. It is very important, so please read it.

Part 2: Product Specifications

This section outlines and specification.

Part 3: Operating Instructions

This section explains how to operate the unit properly. Information required about installation and service made.

Part 4: Technical Reference

This section outlines the way the unit operates so you can understand it technically.

Part 5: Maintenance

This section explains how to maintain the unit. Descriptions of assembly/disassembly, adjustment for assembly, troubleshooting procedures, and wiring/circuit diagrams are given.

Procedures for assembly/disassembly are not given in this manual.
See the illustrations in the separate Parts Catalog.

II. TABLE OF CONTENTS

Page

Part 1: Safety and Precautions

1 - 1 1. SAFETY PRECAUTIONS
1 - 1 1.1 Moving Parts
1 - 2 1.2 Ink Stains
1 - 2 1.2.1 Ink path
1 - 3 1.2.2 Ink mist
1 - 4 1.3 BJ Cartridge Heat-Up
1 - 5 2. MACHINE PRECAUTIONS
1 - 5 2.1 Precautions for Handling BJ Cartridges
1 - 5 2.1.1 Turning the printer ON/OFF
1 - 5 2.1.2 When the printer is not in use
1 - 5 2.1.3 Transportation precautions
1 - 5 2.1.4 Ink electroconductivity
1 - 6 2.2 Printer Precautions
1 - 6 2.2.1 Spur deformation prevention
1 - 6 2.2.2 Static electricity damage prevention
1 - 7 3. PRECAUTIONS FOR SERVICE
1 - 7 3.1 EEPROM Data Precautions
1 - 8 3.2 Static Electricity Precautions
1 - 8 3.3 Disassembly and Reassembly Precautions
1 - 8 3.4 Self-Diagnosis

Part 2: Product Specifications

2 - 1 1. PRODUCT OUTLINE
2 - 1 1.1 Product Outline
2 - 2 1.2 Features
2 - 3 1.3 BJ Cartridge
2 - 3 1.3.1 Color BJ cartridge (Multi-Drop)
2 - 3 1.3.2 Black BJ cartridge
2 - 3 1.3.3 Photo BJ cartridge (Multi-Drop)
2 - 4 1.4 BJ Cartridge Container
2 - 4 1.5 Consumables
2 - 4 1.5.1 BJ cartridges (Color, Black, Photo)
2 - 4 1.5.2 Ink cartridge (Color BJ cartridge)
2 - 5 1.6 Option
2 - 5 1.6.1 Color image scanner cartridge
2 - 5 1.6.2 Scanning holder
2 - 5 1.6.3 White calibration sheet
2 - 6 2. SPECIFICATIONS
2 - 6 2.1 Printer Specifications
2 - 9 2.2 Scanner Cartridge Specifications (Option)
2 -10 2.3 Paper Specifications
2 -10 2.3.1 Paper size
2 -10 2.3.2 Paper type (Recommended)
2 -10 2.3.3 Paper setting
2 -11 2.3.4 Printable area
2 -12 2.4 Interface Specifications

Part 3: Operating Instructions

3 - 1 1. PRINTER SETUP
3 - 1 1.1 Equipment Check
3 - 2 1.2 Printer Dimensions
3 - 3 1.3 Setup Procedure

Page
3 - 3 1.3.1 Connecting the interface cable
3 - 3 1.3.2 Turning on the printer
3 - 4 1.3.3 Installing the cartridge
3 - 6 1.3.4 Scanner cartridge precautions
3 - 7 1.3.5 Replacing the ink cartridge
3 - 9 1.3.6 BJ cartridge container
3 -10 1.4 Turning the Printer On/Off
3 -10 1.4.1 Turning the printer on
3 -10 1.4.2 Turning the printer off
3 -11 1.5 Paper Settings
3 -11 1.6 Banner Printing
3 -12 1.7 Scanning Precautions
3 -13 1.8 Name of the Parts and Their Functions
3 -15 2. PRINTER SERVICING FUNCTIONS
3 -15 2.1 Error Indications
3 -17 2.2 Cleaning the BJ Cartridge
3 -17 2.3 Self-Test Printout
3 -17 2.3.1 Nozzle check pattern
3 -18 2.3.2 Service test print
3 -19 2.4 EEPROM Reset
3 -19 2.4.1 EEPROM Reset
3 -19 2.4.2 Printing the EEPROM data

Part 4: Technical Reference

4 - 1 1. OVERVIEW
4 - 1 1.1 Printer Diagram
4 - 2 1.2 Print Signal Flow
4 - 3 1.3 Print Drive
4 - 3 1.3.1 Printing drive control
4 - 5 2. FIRMWARE
4 - 5 2.1 720 dpi Printing Feature
4 - 5 2.1.1 Canon extended mode
4 - 6 2.2 Printing Modes
4 - 6 2.2.1 Printing mode
4 - 6 2.2.2 Photo print mode
4 - 6 2.2.3 Multi-drop print mode
4 - 8 2.3 Optimum Printing Direction Control
4 - 8 2.4 Ink Smear Control
4 - 8 2.5 Head Overheating Protection Control
4 - 9 3. PRINTER MECHANICAL SYSTEM
4 - 9 3.1 Overview
4 - 9 3.1.1 Mechanical components
4 -10 3.2 BJ Cartridge
4 -10 3.2.1 Black BJ cartridge structure
4 -11 3.2.2 Color BJ cartridge structure
4 -12 3.2.3 Photo BJ cartridge structure
4 -13 3.2.4 Bubble head unit structure
4 -17 3.3 Purge Unit
4 -17 3.3.1 Purge unit functions
4 -18 3.3.2 Purge unit structure
4 -19 3.4 Carriage
4 -19 3.4.1 Carriage functions
4 -20 3.4.2 Carriage structure
4 -22 3.5 Paper Feed

Page
4 -22 3.5.1 Outline of the paper feed
4 -23 3.5.2 Structure of the sheet feeder
4 -24 4. PRINTER ELECTRICAL SYSTEM
4 -24 4.1 Overview
4 -25 4.2 Logic Section
4 -25 4.2.1 Logic section block diagram
4 -26 4.2.2 Logic section components
4 -28 5. SENSOR FUNCTIONS
4 -28 5.1 Pick-Up Roller Sensor
4 -28 5.2 Paper End Sensor
4 -28 5.3 Home Position Sensor (Purge Sensor)
4 -28 5.4 Temperature Sensor
4 -29 5.5 Head Temperature Sensor
4 -29 5.6 Waste Ink Amount Detection
4 -30 6. SCANNER CARTRIDGE
4 -30 6.1 Scanner Cartridge Overview
4 -30 6.1.1 Block diagram
4 -31 6.2 Scanner Cartridge Structure
4 -33 6.3 Signal Contacts
4 -33 6.4 Scan Mode
4 -33 6.5 Calibration

Part 5: Maintenance

5 - 1 1. MAINTENANCE
5 - 1 1.1 Parts for Regular Replacement
5 - 1 1.2 Consumables
5 - 1 1.3 Periodic Maintenance
5 - 2 2. SERVICING TOOLS
5 - 2 2.1 List of Tools
5 - 3 3. GREASE APPLICATION
5 - 4 4. DISASSEMBLY AND REASSEMBLY
5 - 4 4.1 Disassembly and Reassembly
5 - 4 4.2 Disassembly and Reassembly Cautions
5 - 5 4.3 Logic Board and Bottom Cover Replacement Cautions
5 - 5 4.3.1 Logic board replacement cautions
5 - 5 4.3.2 Cautions after replacing the bottom cover
5 - 6 5. TROUBLESHOOTING
5 - 6 5.1 Troubleshooting
5 - 6 5.1.1 Overview
5 - 6 5.1.2 Troubleshooting cautions
5 - 8 5.2 Error Condition Diagnosis
5 - 8 5.2.1 Initial self check
5 -10 5.2.2 Error recovery
5 -23 6. LOCATION & SIGNAL ASSIGNMENT
5 -23 6.1 Logic Board
5 -25 6.2 Carriage Ribbon Cable
5 -26 6.3 BJ Cartridge & Scanner Cartridge
5 -28 7. CIRCUIT DIAGRAMS
5 -28 7.1 Parts Layout
5 -28 7.1.1 Logic board

III. ILLUSTRATION INDEX

Page		
1 - 1	Figure 1- 1	Moving Parts of the Printer
1 - 2	Figure 1- 2	Ink Path
1 - 3	Figure 1- 3	Ink Path of the BJ Cartridge
1 - 3	Figure 1- 4	Ink Mist
1 - 4	Figure 1- 5	BJ Cartridge Aluminum Plate
1 - 6	Figure 1- 6	Spurs and Spur Cleaners
1 - 6	Figure 1- 7	Carriage Ribbon Cable's Electrical Contacts
1 - 8	Figure 1- 8	Electrical System of Printer
1 - 8	Figure 1- 9	How to Release Plastic Hooks
2 - 1	Figure 2- 1	Printer Exterior
2 - 3	Figure 2- 2	Color BJ Cartridges
2 - 4	Figure 2- 3	BJ Cartridge Container
2 - 4	Figure 2- 4	Ink Cartridges
2 - 5	Figure 2- 5	Scanner Cartridge
2 - 5	Figure 2- 6	Scanning Holder
2 -11	Figure 2- 7	Printing Area
2 -11	Figure 2- 8	Printing Area (Envelope)
2 -11	Figure 2- 9	Printing Area (Banner Paper)
2 -18	Figure 2-10	Timing Chart (Compatible Mode)
2 -19	Figure 2-11	Timing Chart (Nibble Mode)
2 -20	Figure 2-12	Timing Chart (ECP Mode)
3 - 1	Figure 3- 1	Packaging
3 - 2	Figure 3- 2	Printer Dimension
3 - 3	Figure 3- 3	Connecting the Interface Cable
3 - 4	Figure 3- 4	Removing the BJ Cartridge Protectors
3 - 4	Figure 3- 5	BJ Cartridge Handling Precautions
3 - 5	Figure 3- 6	Cartridge Installation
3 - 6	Figure 3- 7	Scanner Cartridge
3 - 7	Figure 3- 8	Removing the Ink Cartridge
3 - 8	Figure 3- 9	Removing the Ink Cartridge Cap
3 - 8	Figure 3-10	Ink Cartridge Protection
3 - 9	Figure 3-11	BJ Cartridge Container
3 -10	Figure 3-12	Never unplug the power cord less than one minute after completing an operation
3 -11	Figure 3-13	Banner Printing
3 -12	Figure 3-14	Scanning Holder
3 -13	Figure 3-15	Name of the Parts and Their Functions
3 -14	Figure 3-16	Name of the Parts and Their Functions
3 -14	Figure 3-17	Paper Thickness Lever
3 -17	Figure 3-18	Nozzle Check Pattern
3 -18	Figure 3-19	Service Test Print
4 - 1	Figure 4- 1	Printer Diagram
4 - 2	Figure 4- 2	Printing Signal Flow
4 - 3	Figure 4- 3	Printing Sequence (Black BJ Cartridge/HQ Mode)
4 - 4	Figure 4- 4	Printing Signals
4 - 5	Figure 4- 5	720 dpi Printing Feature
4 - 9	Figure 4- 6	Printer's Mechanical Configuration
4 -10	Figure 4- 7	Black BJ Cartridge Structure
4 -11	Figure 4- 8	Color BJ Cartridge Structure
4 -12	Figure 4- 9	Photo BJ Cartridge Structure
4 -13	Figure 4-10	Bubble Jet Nozzles (Partial View)
4 -14	Figure 4-11	Nozzle Arrangement

Page		
4 -14	Figure 4-12	Black BJ Cartridge Block Diagram
4 -15	Figure 4-13	Color (Multi-Drop)/Photo (Multi-Drop) BJ Cartridge Block Diagram
4 -18	Figure 4-14	Purge Unit
4 -19	Figure 4-15	Carriage
4 -20	Figure 4-16	Paper Thickness Adjustment
4 -21	Figure 4-17	Paper Feed Motor Drive Transmission
4 -22	Figure 4-18	Paper Feed Mechanism
4 -23	Figure 4-19	Paper Pick-Up Mechanism
4 -24	Figure 4-20	Printer Electrical System
4 -25	Figure 4-21	Logic Board Block Diagram
4 -25	Figure 4-22	Printer Block Diagram
4 -28	Figure 4-23	Sensors
4 -30	Figure 4-24	Scanner Cartridge
4 -30	Figure 4-25	Block Diagram
4 -31	Figure 4-26	Scanner Cartridge
5 - 3	Figure 5- 1	Grease Application Points
5 - 5	Figure 5- 2	Bottom Cover
5 -23	Figure 5- 3	Logic Board
5 -25	Figure 5- 4	Carriage Ribbon Cable
5 -26	Figure 5- 5	Contact Pad
5 -28	Figure 5- 6	Logic Board (Top View)

IV. TABLE INDEX

Page		
3 -11	TABLE 3- 1	QUICK REFERENCE FOR SETTING
3 -15	TABLE 3- 2	ERROR INDICATIONS
3 -19	TABLE 3- 3	DEFAULT SETTING WHEN RESETTING THE EEPROM
4 - 7	TABLE 4- 1	PRINTING MODES AND HEATING METHODS
4 -16	TABLE 4- 2	HEAD INSTALLATION STATUS AND SIGNAL DETECTION
4 -17	TABLE 4- 3	INK CONSUMPTION DURING CLEANING (AS A STANDARD)
4 -29	TABLE 4- 4	LIST OF SENSOR FUNCTIONS
4 -33	TABLE 4- 5	LIST OF SCAN MODE